

## IGNITION SWITCH

**ARM NO: 00.09.48.0001**



Kontak Anahtarı  
IGNITION SWITCH  
DESCRIPTION: Ignition Caps  
MAN

OEM NO: 001 462 1130

**ARM NO: 00.09.48.0002**



Kontak Anahtarı  
IGNITION SWITCH  
DESCRIPTION: Ignition Switch  
MERCEDES BENZ  
BOSCH

OEM NO: 1716013 - 0342 106 005  
000 545 3013 - 960829130009

**ARM NO: 00.09.48.0003**



Kontak Anahtarı  
IGNITION SWITCH  
DESCRIPTION: Steering Lock

OEM NO: 641 720 0346

**ARM NO: 00.09.48.0004**



Kontak Anahtarı  
IGNITION SWITCH  
DESCRIPTION: Ignition Switch  
BENZ BUS

OEM NO:

**ARM NO: 00.09.48.0005**



Kontak Anahtarı  
IGNITION SWITCH  
DESCRIPTION: Ignition Switch

OEM NO: 0342 309 008

**ARM NO: 00.09.48.0006**



Kontak Anahtarı  
IGNITION SWITCH  
DESCRIPTION: Ignition Caps

OEM NO: 000 545 5413

**ARM NO: 00.09.48.0007**



Kontak Anahtarı  
IGNITION SWITCH  
DESCRIPTION: Steering Lock  
MERCEDES BENZ

OEM NO: 001 462 1130

**ARM NO: 00.09.48.0008**



Kontak Anahtarı  
IGNITION SWITCH  
DESCRIPTION: Ignition Switch

OEM NO: Mn1247  
361552

**ARM NO: 00.09.48.0009**



Kontak Anahtarı  
IGNITION SWITCH  
DESCRIPTION: Ignition Switch

OEM NO: 0342 309 006

**IGNITION SWITCH**

**ARM NO: 00.09.48.0010**



**Kontakt Anahtarı**  
**IGNITION SWITCH**  
 DESCRIPTION: Power Switch  
 STW

**OEM NO: B-193697**

**ARM NO: 00.09.48.0011**



**Kontakt Anahtarı**  
**IGNITION SWITCH**  
 DESCRIPTION: Ignition Switch

**OEM NO: 0342309 004**

**ARM NO: 00.09.48.0012**



**Kontakt Anahtarı**  
**IGNITION SWITCH**  
 DESCRIPTION: Ignition Switch

**OEM NO: Jn162 3708010**

**ARM NO: 00.09.48.0013**



**Kontakt Anahtarı**  
**IGNITION SWITCH**  
 DESCRIPTION: Ignition Switch

**OEM NO: 0342 309 008**

**ARM NO: 00.09.48.0014**



**Kontakt Anahtarı**  
**IGNITION SWITCH**  
 DESCRIPTION: Ignition Caps  
 SCANIA

**OEM NO: 371910**

**ARM NO: 00.09.48.0015**



**Kontakt Anahtarı**  
**IGNITION SWITCH**  
 DESCRIPTION: Ignition Switch

**OEM NO: FT00101KS01**


**ARM NO: 00.09.48.0016**



**Kontakt Anahtarı**  
**IGNITION SWITCH**  
 DESCRIPTION: Ignition Switch  
 ST

**OEM NO: 59000580048**

**ARM NO: 00.09.48.0017**



**Kontakt Anahtarı**  
**IGNITION SWITCH**  
 DESCRIPTION: Ignition Switch

**OEM NO: 361552 - MN1247**

**ARM NO: 00.09.48.0018**



**Kontakt Anahtarı**  
**IGNITION SWITCH**  
 DESCRIPTION: Ignition Switch

**OEM NO: 0342 309 006**

## IGNITION SWITCH

ARM NO: 00.09.48.0019



Kontak Anahtarı  
IGNITION SWITCH  
DESCRIPTION: Ignition Switch

OEM NO:

ARM NO: 00.09.48.0020



Kontak Anahtarı  
IGNITION SWITCH  
DESCRIPTION: Ignition Switch

OEM NO:

ARM NO: 00.09.48.0021



Kontak Anahtarı  
IGNITION SWITCH  
DESCRIPTION: Ignition Switch

OEM NO:

ARM NO: 00.09.48.0022



Kontak Anahtarı  
IGNITION SWITCH  
DESCRIPTION: Ignition Switch

OEM NO: 0342 309 008

ARM NO: 01.09.48.0023



Düğme  
SWITCH  
DESCRIPTION: BENZ

OEM NO: A667 545 0013

ARM NO: 01.09.48.0024



Düğme  
SWITCH  
DESCRIPTION: BENZ

OEM NO: A655 545 0008

ARM NO: 01.09.48.0025



Düğme  
SWITCH  
DESCRIPTION: BENZ

OEM NO: A000 545 9508

**ARM<sup>®</sup>**  
spare part products

**ARM<sup>®</sup>**  
spare part products